

SkipDr Replacement Kit Quick Start Guide

- 1. REMOVE** any disc from the repair device before replacing the FlexiWheel™.
- 2. PULL** the used FlexiWheel™ out of the repair device (slip finger behind the wheel, getting as close to the center as possible to pop it off of the hub prongs)(See Fig. 1).



Fig. 1

- 3. INSERT** a new FlexiWheel™ into the device, align with the hub prongs and press firmly to attach the wheel (See Fig. 2).



Fig. 2



Fig. 3

Note: The flat side of the FlexiWheel™ should be facing out (See Fig. 3). It may be necessary to slightly rotate or jiggle the wheel to position it onto the hub prongs.